User Interface

Soft Keys

The phone has five softkeys with status LEDs, which provide several functions dependent on a particular situation.






Example: Telephone menu

Example: Conversation list

By pressing the key you can activate e.g. Call Forwarding.

Navigation Keys




Toggle to menu

Scroll upwards Hold down: Jump to top of list Confirm input or perform action

Step down one menu level Scroll downwards

Cancel function, delete characters left of the cursor, step up one menu level

Audio Keys



Notification-LED

With the Notification LED different phone status can be identified:




Off: Idle Green solid: Active call Green solid: Active call
Green pulsing: Incoming call
Amber solid: Call(s) on hold
Amber pulsing: Held call re-presenting
Red solid: New missed call

Function-Icons (selection)

| Icon | Explanation |
|---------------|------------------------------------|
| | Accept call |
| | Reject call |
| 5.2 | Deflect call |
| (E) | Place call on hold |
| 8 | Transfer call without consultation |
| | Transfer call with consultation |
| 8 | Alternate |
| 47 | Resume held call |
| 650ts 7505 | Request call back |
| (4) | Add participant |
| 磁 | Show participant details |
| 100 | Show all participants |

Status-Icons (selection)

| Icon | Explanation |
|------------|---|
| → J | Incoming call |
| ←) | Outgoing call |
| (1) | Active call |
| П | You have placed the call on hold |
| יי | Your call partner has placed the call on hold |
| 8 8 | Secure/unsecure call |
| ×× | Missed call new/seen |





Using your OpenScape Desk Phone CP600

Place a call

- · Lift handset, dial number or
- · Dial number and lift handset or
- For handsfree mode or if headset is connected: dial number.

Answer a call

- · Lift handset or
- for handsfree mode: press or
- if headset is connected: press ①.

End a call

- · Hang up, or
- For handsfree mode: press or
- If headset is connected: press .

Dial from Conversation List

- 1. Press Soft Key "Conversations" from Menu screen.
- 2. Press ◆ and ◆ to select the desired conversation or type in start of name.
- 3. Press on and lift handset.

Open listening

During a call with handset:

• Press 🖜.

Switch off open listening:

• Press 🕥.

Switch between Handset and Handsfree Mode

Switch to handsfree mode during a Call:

- Hold down **(1)** until you hang up handset.
- Switch to handset:
 Lift handset.

Using your OpenScape Desk Phone CP600

Consultation

During a call with Party A:

- 1. Press O. Party A is put on hold.
- 2. Call Party B.
- 3. If the conversation with Party B is finished, press or wait, until Party B has hang up.

You are now connected again to Party A.

Toggle

During a call with Party A:

- 1. Press . Party A is put on hold.
- 2. Call Party B.
- 3. If connected to Party B, press "Toggle" , to toggle. Pressing "Toggle" repeatedly toggles between Party A and B.

Make a conference call

During a call with party A:

- 1. Press . Party A is automatically put on hold.
- 2. Call party B.
- 3. Once connected with party B, press "Conference" . You are now connected in a conference with parties A and B.

Transfer a call

During a call with party A:

- 1. Press . Party A is automatically put on hold.
- 2. Call party B.
- 3. Once connected with party B, press "Transfer" . Alternatively, the call can be transferred already before announcing the call.

The party A will be transfered to party B.

Call back

- 1. Call an internal Party. The Party does not lift the handset or is busy.
- 2. Press on, the call back is activated.
- 3. As soon as the not reached Party has hung up, the callback is triggered and your telephone rings..
- 4. Answer the call back. The not reached Party is called.

Using your OpenScape Desk Phone CP600

Program Call Forwarding for all Calls

- 1. Press .
- 2. Select "Forward all calls" with \(\delta\).
- 3. Press Soft Key 🗷.
- 4. Enter the destination number and press or .
- 5. Press .

Turn Call Forwarding on/off for all Calls

- Press 🗗.
- Press Soft Key "Without condition" to toggle between on/off.

Program Favourites

- 1. Press **=**.
- 2. Press Soft Key "Favourites".
- 3. Press Soft Key 🖋 to enter edit mode.
- 4. Press Soft Key 💇 to enter desired Soft Key.
- 5. Press Soft Key oto enter normal key function.
- 6. Press ◆ and ◆ to select the desired function.
- 7. Press Soft Key 🗸 to confirm.
- 8. If required, edit the label and/or settings.
- 9. Press Soft Key 🗸 to save your changes.

Press Soft Key 🗸 to leave Favourites edit mode.